

COBRA52235 User's Manual

Version 1.0: 2007/05/12

This document describes the components of the COBRA52235 Starter Kit and the installation and set-up of the board.

Contents:

- 1 First Steps with the COBRA52235 Starter Kit**
- 2 COBRA52235 Hardware Details**
- 3 Software of the COBRA52235**




Figure 1: COBRA52235 module, side view




Figure 2: COBRA52235 module and functions

1 First Steps with the COBRA52235 Starter Kit

The COBRA52235 (see figures 1 and 2) is a versatile controller module with the Freescale MCF52235 microcontroller. The main features are:

- ColdFire® MCF52235 Controller - 60 MHz, up to 57 MIPS
- 256 kByte internal Flash, 32 kByte internal SRAM
- 10/100 Mbit/s Ethernet Interface
- RJ45 Ethernet Connector
- Cryptographic Acceleration Unit
- Three RS232 Interfaces with drivers
- QSPI and I²C bus Interface
- CAN 2.0B Interface
- 2 x 4 channel 12-bit A/D Converter
- 4 channel DMA Controller
- Several 16- and 32-bit Timers
- Standard BDM Interface
- Real Time Clock with separate Backup Battery
- Function LED for Status and Debug Information
- Single 5 V Operating Voltage
- 2x 50-Pin Module Connector Areas
- Dimensions 86 mm x 54 mm
- NicheTask Open Source RTOS with TCP/IP Stack and Embedded Webserver available.

The COBRA52235 starter kit consists of the following components:

- One COBRA52235 module
- A supply voltage connector cable
- One short RS232 connector cable
- A CD with documentation and software
- A CD with CodeWarrior Development Studio for ColdFire, Special Edition
- A printed version of the COBRA52235 Quick Start Guide




Figure 3: Power Supply Circuit of the COBRA52235

To start working with the COBRA52235 the following steps are required:

1. Connect a 5V power supply to the supply voltage connector J0101 of the COBRA52235 module. You can use the supply voltage connector cable which is provided in the starter kit. You should ensure, that the +5V supply voltage is connected to pin 1 of the connector J0101 and GND is connected to pin 2 and/or pin 3 of the connector J0101 (see figure 3). The supply voltage should be $5V \pm 1V$ (4 ... 6 V), the power supply should be able to provide up to 500mA supply current.

There is no reverse polarity protection on the COBRA52235, so you should avoid any false connection of the supply voltage!

2. Make sure the supply voltage jumper JP0101 is connected in position 1-2. The 3.3V supply voltage for the MCF52235 microcontroller is provided by the voltage regulator U0101. The power LED0101 indicates that supply voltage is present.
3. You can connect UART0 of the module via the RS232 cable of the starter kit to a PC and observe the boot message of the COBRA52235 module in a terminal (see figure 4). The settings for the serial connector of the PC should be the following: 8N1, 115 kbit/s.

```

Tera Term - COM1 VT
File Edit Setup Control Window Help
Running ColdFire TCP/IP-Lite stack
Copyright 2006 by Freescale Semiconductor Inc.
Use of this software is controlled by the agreement
found in the project LICENSE.H file.
Built on May 8 2007 14:42:38

COBRA52235 by senTec Elektronik
U: 01-01

Heap size = 24064 bytes
etheraddr = 00:CF:52:23:00:00

Starting ints.
Calling netmain(>)...
InterNiche ColdFireLite TCP/IP for Coldfire, v3.0

Copyright 1997-2006 by InterNiche Technologies. All rights reserved.
Preparing device for networking
Ethernet started, Iface: 0, IP: 192.168.0.31
IP address of : 192.168.0.31
INET> █

```

Figure 4: Boot message of the COBRA52235 module in a terminal



Figure 5: Pre-programmed website on the COBRA52235 module

4. You can connect the Ethernet interface of the COBRA52235 module to a PC, using a "Cross" Ethernet cable. Please note that a "Straight" Ethernet cable cannot be used for direct connection of the module to a PC. The preconfigured IP address of the COBRA52235 module is 192.168.0.31. The module comes with a pre-programmed TCP/IP stack and web server. You can observe the website in any standard web browser (see figure 5). Please note that you have to configure your PC in a way that it is located in the same network segment in order to view the website. For example, you can use these PC settings: IP address: 192.168.0.31, Network mask: 255.255.255.0, Default Gateway: 192.168.0.254
5. By pressing the button "LED_TOGGLE" on the web site (figure 5), you can toggle the function LED on the COBRA52235 module.

2 COBRA52235 Hardware Details

The block diagram of the COBRA52235 module is provided in figure 6. You can see that the most important component is the MCF52235 microcontroller. It is combined with a real time clock with watchdog and backup battery.




Figure 6: Block Diagram of the COBRA52235 module

The real time clock is powered from a separate battery, so the time will not be lost when the supply voltage is disconnected. A 32 kHz quartz crystal provides an independent time base for the real time clock. The MCF52235 has three serial communication interfaces. These are connected to the UART 0-2 connectors of the module via a RS323 driver each.

The block diagram of the MCF52235 microcontroller is provided in figure 7. It features a ColdFire V2 core which is clocked with 60 MHz. ColdFire is a 32-bit CPU core of Freescale semiconductor and is compatible to the industry standard 68k architecture. The MCF52235 has 256 kByte Flash and 32 kByte SRAM. Moreover it has various communication interfaces, including an Ethernet MAC (Media Access Controller) and PHY (Physical Layer). Therefore, the COBRA52235 is ideally suited to be used as an Embedded Ethernet interface or serial-to-Ethernet bridge.




Figure 7: Block diagram of the MCF52235 microcontroller

The interfaces and signals of the MCF52235 microcontroller are connected to the pins of the two 50-pin module connectors. For exact information of the assigned pins refer to the schematics of the COBRA52235 and to table 1.

Module Connector J0501				Module Connector J0502			
Pin	Function	Pin	Function	Pin	Function	Pin	Function
50	Vdd +5V	49	Vdd +3.3V	50	Vdd +3.3V	49	Vdd +5V
48	GND	47	GND	48	GND	47	GND
46	/RSTI	45	/RSTO	46	DDATA0	45	PST0
44	/RCON	43	/URTS0	44	DDATA1	43	PST1
42	QSPI_DOUT	41	/UCTS0	42	DDATA2	41	PST2
40	QSPI_DIN	39	URXD0	40	DDATA3	39	PST3
38	QSPI_CLK	37	UTXD0	38	DTIN0	37	SYNCB
36	QSPI_CS0	35	/URTS1	36	DTIN1	35	SYNCA
34	QSPI_CS1	33	/UCTS1	34	DTIN2	33	IIC_SDA
32	QSPI_CS2	31	URXD1	32	DTIN3	31	IIC_SCL
30	QSPI_CS3	29	UTXD1	30	IRQ15	29	GPT0
28	/IRQ7	27	/URTS2	28	IRQ14	27	GPT1
26	/IRQ6	25	/UCTS2	26	IRQ13	25	GPT2
24	/IRQ5	23	URXD2	24	IRQ12	23	GPT3
22	/IRQ4	21	UTXD2	22	IRQ11	21	PWM7
20	/IRQ3	19	IRQ_RTC	20	IRQ10	19	PWM5
18	/IRQ2	17	LED_ACT	18	IRQ9	17	PWM3
16	/IRQ1	15	LED_LINK	16	IRQ8	15	PWM1
14	LED_SPEED	13	PHY_TXP	14	GND	13	GND
12	LED_DUPLEX	11	PHY_TXN	12	AN1	11	AN0
10	LED_COLL	9	PHY_RXP	10	AN3	9	AN2
8	LED_RX	7	PHY_RXN	8	AN6	7	AN7
6	LED_TX	5	Vdd_BAT	6	AN4	5	AN5
4	GND	3	GND	4	GND	3	GND
2	Vdd +5V	1	Vdd +3.3V	2	Vdd +3.3V	1	Vdd +5V

Table 1: COBRA52235 Module Connectors

3 Software of the COBRA52235

The COBRA52235 module is shipped with a pre-programmed Ethernet driver, TCP/IP stack and pre-loaded sample website.

The TCP/IP stack on the COBRA52235 is the "ColdFire_TCP/IP_Lite" stack from Interniche. This is an Open Source embedded TCP/IP stack with the following features:

- A mini-Sockets TCP API.
- A TFTP server.
- A DHCP client.

- Zero-copy sockets for optimum performance.
- Less then 40kByte of program space required.

The mini-Sockets TCP API is designed to be as close as possible to the BSD (Berkeley Software Distribution) Sockets API and still allow a small footprint. The primary differences are that passive connections are accomplished with a single call, `m_listen()`, rather than the BSD `bind()` - `listen()` - `accept()` sequence, and the BSD `select()` call is replaced with a callback mechanism.

```

Tera Term - COM1 VT
File Edit Setup Control Window Help
IP address of : 192.168.0.31
INET> ephy_handler
100bT Full Dup
Interrupt Register Register      = 7F00
INET> ?
SNMP Station: general commands:
  help      - help with menus
  state     - show current station setup
  delay     - set milliseconds to wait between pings
  host      - set default active IP host
  length    - set default ping packet length
  quit      - quit station program
  ping      - send a ping
  setup     - set interface IP address
  version   - display version information
  !command  - pass command to OS shell
  setrtc    - Set time of RTC (yyyymmddhhmmss)
  readrtc   - Read time of RTC
Also try 'help [general!diagnostic!EMG HTTP!
INET>
  
```

Figure 8: Serial User Interface of the NicheTask RTOS

The ColdFire_Lite TCP/IP stack includes the Real Time Operating System NicheTask. This is an Open Source RTOS with the following features:

- Tasks are supported with message rings, and separate stacks.
- Priorities are supported.
- Task Sleeping support.
- Tasks can sleep waiting on an event.

The RTOS provides a serial user interface to the terminal console for configuration, diagnostic and debug purposes (figure 8).

More information about the NicheTask Open Source RTOS can be found at <http://www.freertos.com>.

Moreover, the software of the COBRA52235 module contains an embedded web server from Freescale. The features of the web server are the following:

- HTTP1.0 compliant server with connection persistence and multiple sessions (HTTP1.1 will be available in future revisions).
- GET and POST elements supported.
- Dynamic HTML support with replace and conditional tokens.
- Serial interface support for Dynamic HTML variables.

- Provides run time and compile time flash file systems.
- Long file name support with subdirectories.
- 'DIR' command supported on serial interface.
- PC utilities for compressing compile time and run time downloadable images of multi-page web pages.
- PC utility for downloading run time downloadable web page image through port 80 (to get through firewalls).
- 32 byte ascii key for web page download security.
- It's free for use on Freescale's *ColdFire*® processors.





Figure 9: Software Structure of the COBRA52235 module

The content of the CD in the COBRA52235 starter kit box has the following structure:



The original source code project of the ColdFire_Lite TCP/IP stack and the Freescale web server can be found at:

CD:\Software\ColdFire_Lite\build\mwerks\m5223evb\ColdFire_Lite.mcp

To open this project file you should install the CodeWarrior Development Studio for ColdFire, Special Edition. This version is free of charge and does not require any license file, but it is limited to a maximum size of 128 kByte code.

The COBRA52235 starter kit contains a CD with CodeWarrior Development Studio for ColdFire, Version 6.3. You should install this software on your PC in order to compile, build and debug software projects for ColdFire processors. If you install the software of the CD, the free of charge "Special Edition" of CodeWarrior will be installed automatically. If you wish you can register this product, but there is no technical need to do so. The free of charge "Special Edition" of CodeWarrior is limited to a maximum size of 128 kByte code of your project. If you want to build a project with more than 128 kByte of code, you should purchase an update version of the CodeWarrior Development Studio for ColdFire.




Figure 10: ColdFire_Lite TCP/IP stack as CodeWarrior project

The ColdFire_Lite TCP/IP stack including RTOS, Freescale web server and compile time file system requires less than 128 kByte, so the Special Edition of CodeWarrior Development Studio for ColdFire is sufficient to build this project. However, you have to purchase a BDM interface for ColdFire in order to flash and debug the software you have created with the CodeWarrior compiler. This BDM interface can be a USB Multilink for ColdFire or you can use a **COBRA Connect BDM Interface** from senTec Elektronik.

Using CodeWarrior you can browse the source code of the TCP/IP stack and the web server. You can translate the source code and flash the result into the memory of the MCF52235. However, having the COBRA52235 module, you can use as well the pre-programmed web server. Detailed information about the ColdFire_Lite TCP/IP stack can be found in the folder:

CD:\Software\ColdFire_Lite\docs

The source of the original website served by the COBRA52235 can be found in the folder:

CD:\Software\Compile_Time_Web_Page\COBRA52235_Static_Homepage

It is possible to re-load the website served by the web server during run time of the server. These run time loadable websites are loaded into the second 128 kByte page of the total available 256 kByte flash memory. On the CD there are four examples for re-loadable websites in the folders:

CD:\Software\Run_Time_Loaded_Web_Pages\Static_Homepage

CD:\Software\Run_Time_Loaded_Web_Pages\Dynamic_Homepage_IO-Demo

**CD:\Software\Run_Time_Loaded_Web_Pages\Dynamic_Homepage_Game
_Hexxagon**

**CD:\Software\Run_Time_Loaded_Web_Pages\Dynamic_Homepage_Game
_Space-Invaders**

Each of these folders contains a file "make.bat". In order to re-load the web page during run time of the web server you should connect the PC via Ethernet to the COBRA 52235 and then start the "make.bat" file in the folder. A batch is started and the following steps are executed:

- The files which are specified in "filelist.txt" are converted into an image of the new web site.
- The image of the new web site is uploaded to the web server. For this upload the password "CB52235CB" is used, which is specified in the "make.bat" file.

The Folder **CD:\Software\Run_Time_Loaded_Web_Pages\Static_Homepage** contains a simple static website. Start the file "make.bat" during run time of the web server in order to load this website.

The other Folder **CD:\Software\Run_Time_Loaded_Web_Pages\Dynamic_Homepage_IO-Demo** contains another project, which displays the analog value, measured on AD/Converter 1. The two other bars are able to visualise the input data from the serial terminal.

The two Folders **CD:\Software\Run_Time_Loaded_Web_Pages\Dynamic_Homepage_Game_Space-Invaders** and **Game_Hexxagon** contain two popular retro computer games which can be loaded into the COBRA52235, including the well known Space Invaders (Figure 11).




Figure 11: Space Invaders served by the COBRA52235

In order to delete the re-loaded website and display the original pre-programmed site (Figure 5), you should go the folder:

CD:\Software\Run_Time_Loaded_Web_Pages\COBRA52235_Homepage_Erase

This folder contains an empty project for a re-loadable site and an empty "filelist.txt". If the "make.bat" is started, the existing re-loaded website will be overwritten and the original pre-programmed site will be displayed.

© Copyright senTec Elektronik GmbH, 2007 - <http://www.sentec-elektronik.de>